



Whitewater
Designs, Inc.

HOW TO USE CAM BUCKLE STRAPS TO SECURE YOUR BOAT TO THE ROOF RACK OF YOUR VEHICLE



Figure 1

1) Hold the buckle in one hand and throw the other end of the strap over the boat. Leave the buckle hanging (see fig.1) and go to the other side of the vehicle.

2) Lace the strap under the crossbar, close to the boat. Keep the strap from crossing over itself and throw the end back over the boat (see fig.2). By not crossing the strap, adjustment of the buckle height will be easier.



Figure 2

3) Go back where you started and lace the end of the strap under the crossbar, close to the boat. The buckle should be placed high enough on the boat to be able to pull down comfortably when tightening the strap.

4) Press the tab on the buckle and insert the end of the strap into the underside of the buckle. Continue pressing on the tab as you pull the strap through until the strap over the boat is no longer loose. Release the tab on the cam buckle.



Figure 3



Figure 4

5) Pull down on the strap end to tighten (see fig.3). It may be necessary to stop the buckle from moving as you pull on the strap end.

6) Repeat this process for the other crossbar.

7) Strap the bow and stern to the bumper or some other secure part of the car (see fig.4) and you are ready to go to the river, lake or across the country.

Disclaimer: Whitewater Designs, Inc. does not assume responsibility for defects, damages or injuries caused by misuse, abuse, alteration, repair by others or unsuitability as to applications or load bearing strength. Notwithstanding anything to the contrary contained in any information or promotional materials furnished by Whitewater Designs, Inc., all sales of Whitewater Designs, Inc. are governed exclusively by its standard terms and conditions which include disclaimers of liability.